Installation

Residential/Light Commercial Generator Sets



Models:

24RCLA 30RCLA 38RCLC

Controller:

RDC2

▲ WARNING: This product can expose you to chemicals, including carbon monoxide and benzene, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov

Kohler strongly recommends that only factory-authorized dealers install and service the generator.

Product Identification Information

Generator Set lo	dentification Numbers	Engine Identification
Record the product ic generator set nameplate	lentification numbers from the te(s).	Record the product identification information from the engine nameplate.
Model Designation		Manufacturer
Specification Number _		Model Designation
Serial Number		Serial Number
Accessory Number	Accessory Description	Controller Identification
		Record the controller description from the generator set operation manual, spec sheet, or sales invoice.
		Controller Description

Table of Contents

Safety Precaut	ions an	ıd Instru	ctions	5
Introduction .				9
Service Assist	ance			10
Section 1 Insta	allation	Instruct	ions	11
	1.1		otion	11
	1.2		Generator Set	12
	1.3	•	n and Mounting	14
	1.0	1.3.1	Location Factors	14
		1.3.2	Mounting Surface	14
		1.3.3	Vibration Isolation	14
		1.3.4	Prepare Site	15
		1.3.5	Mount the Generator Set	15
	1.4		al System	16
		1.4.1	Electrical Connections	17
		1.4.2	Terminal Connector Torque	18
		1.4.3	Ground and Neutral Connections	19
		1.4.4	Battery Chargers	19
		1.4.5	Power Supply	19
		1.4.6	Connect AC and DC Wiring	19
		1.4.7	Automatic Transfer Switch Connection	22
		1.4.8	Communication Cable Specifications	25
		1.4.9	System Connections with Accessory Modules	26
		1.4.10	Other Accessories	28
	1.5	Engine	Starting Battery	29
	1.6	Fuel Sy	stem	30
		1.6.1	Fuel Lines	31
		1.6.2	Gas Regulators	32
		1.6.3	Install and Connect Fuel Supply	32
		1.6.4	Fuel Conversion Procedures	33
	1.7	Cooling	System	34
	1.8	Prestar	Installation Check	35
	1.9	Set Exe	rciser	36
	1.10	Operati	on Tests	36
	1.11		Plus Generator Management System	37
Section 2 Acc	essorie			39
	2.1		ation	39
	2.2		Heaters	39
	2.3	-	ency Stop Kits	40
	2.4	_	anagement	40
	2.4	2.4.1	Power Relay Module	41
	2.5		Plus Wireless Kit	41
	2.6		nmable Interface Module (PIM)	42
	۷.0	2.6.1	PIM to Generator Set Connections	42
		2.6.2	PIM Inputs and Outputs	42
	2.7		Heaters	43
	۷.1	2.7.1	Oil Pan Heaters	43
		272	Block Heaters	43

Table of Contents, continued

Section 3 Generator	Reconnection	45
3.1	Voltage Reconnection	45
3.2	Four-Lead (Single-Phase) Generator Sets	46
3.3	12-Lead (Three-Phase) Generator Sets	46
3.4	Changing System Settings	49
3.5	Voltage Calibration	52
	3.5.1 Calibration using the RDC2 Controller Keypad and Menus	52
	3.5.2 Calibration Using SiteTech	54
Section 4 Diagrams	and Drawings	57
Appendix A Abbrevia	ations	77

4 Table of Contents TP-7202 6/22

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. SAVE THESE INSTRUCTIONS.

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.



DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Press the generator set off/reset button to shut down the generator set. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

Battery



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.



Explosion.

Can cause severe injury or death. Relays in the battery charger cause arcs or sparks.

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded

metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury

Short circuits can cause bodily injury and/or equipment damage. Disconnect the batterv before installation generator set maintenance. Remove all iewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Engine Backfire/Flash Fire



Risk of fire. Can cause severe injury or death.

Do not smoke or permit flames or sparks near fuels or the fuel system.

Servicing the fuel system. A flash fire can cause severe injury or death. Do not smoke or permit flames or sparks near the carburetor, fuel line, fuel filter, fuel pump, or other potential sources of spilled fuels or fuel vapors. Catch fuels in an approved container when removing the fuel line or carburetor.

Servicing the air cleaner. A sudden backfire can cause severe injury or death. Do not operate the generator set with the air cleaner removed.

Combustible materials. A fire can cause severe injury or death. Generator set engine fuels and fuel vapors are flammable and explosive.

Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or for electrical fires or as recommended by the local fire code or an authorized agency. Train all extinguisher personnel on fire prevention operation and fire procedures.

Exhaust System



Carbon monoxide.
Can cause severe nausea, fainting, or death.

The exhaust system must be leakproof and routinely inspected.

Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building. Never operate the generator set where exhaust gas could seep inside or be drawn into a potentially occupied building through windows, air intake vents, or other openings.

Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down,

or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

Carbon monoxide detectors. Carbon monoxide can cause severe nausea, fainting, or death. Install carbon monoxide detectors on each level of any building adjacent to the generator set. Locate the detectors to adequately warn the building's occupants of the presence of carbon monoxide. Keep the detectors operational at all times. Periodically test and replace the carbon monoxide detectors according manufacturer's instructions.

Fuel System



Explosive fuel vapors.
Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

The fuel system. Explosive fuel vapors can cause severe injury or death. Vaporized fuels are highly explosive. Use extreme care when handling and storing fuels. Store fuels in a well-ventilated area away from spark-producing equipment and out of the reach of children. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks. Do not smoke or permit flames or sparks to occur near sources of spilled fuel or fuel vapors. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines. Use flexible sections to avoid fuel line breakage caused by vibration. Do not operate the generator set in the presence of fuel leaks, fuel accumulation, or sparks. Repair fuel systems before resuming generator set operation.

Explosive fuel vapors can cause severe injury or death. Take additional precautions when using the following fuels:

Propane (LPG)—Adequate ventilation is mandatory. Because propane is heavier than air, install propane gas detectors low in a room. Inspect the detectors per the manufacturer's instructions.

Natural Gas—Adequate ventilation is mandatory. Because natural gas rises, install natural gas detectors high in a room. Inspect the detectors per the manufacturer's instructions.

Gas fuel leaks. **Explosive fuel** vapors can cause severe injury or death. Fuel leakage can cause an explosion. Check the LPG vapor or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6-8 ounces per square (10-14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

Hazardous Noise





Hazardous noise. Can cause hearing loss.

Never operate the generator set without a muffler or with a faulty exhaust system.

Engine noise. Hazardous noise can cause hearing loss. Generator sets not equipped with sound enclosures can produce noise levels greater than 105 dBA. Prolonged exposure to noise levels greater than 85 dBA can cause permanent hearing loss. Wear hearing protection when near an operating generator set.

Hazardous Voltage/ Moving Parts

A DANGER



Hazardous voltage. Will cause severe injury or death.

Disconnect all power sources before opening the enclosure.

A DANGER





Hazardous voltage. Moving parts. Will cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.

A WARNING



Hazardous voltage. Backfeed to the utility system.

Can cause property damage, severe injury, or death.

If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

▲ DANGER



Hazardous voltage. Will cause severe injury or death.

This equipment must be installed and serviced by qualified electrical personnel.

A CAUTION

Welding the generator set.

Can cause severe electrical equipment damage.

Welding on generator set will cause serious damage to engine electronic controls components. Disconnect all engine electronic control connections before welding.

Grounding electrical equipment. Hazardous voltage will cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Disconnecting the electrical load. Hazardous voltage will cause severe injury or death. Disconnect the generator set from the load by turning off the line circuit breaker or by disconnecting the generator set output leads from the transfer switch and heavily taping the ends of the leads. High voltage transferred to the load during testing may cause personal injury and equipment damage. Do not use the safeguard circuit breaker in place of the line circuit breaker. The safeguard circuit breaker does not disconnect the generator set from the load

Welding on the generator set. Can cause severe electrical equipment Before welding on the damage. generator set perform the following steps: (1) Remove the battery cables. negative (-) lead first. (2) Disconnect all engine electronic control module (ECM) connectors. (3) Disconnect all generator set controller and voltage regulator circuit board connectors. (4) Disconnect the engine batterycharging alternator connections. (5) Attach the weld ground connection close to the weld location.

Connecting the battery and the battery charger. Hazardous voltage will cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Short circuits. Hazardous voltage/current will cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Engine block heater. Hazardous voltage will cause severe injury or death. The engine block heater can cause electrical shock. Remove the engine block heater plug from the electrical outlet before working on the block heater electrical connections.

Accessing the middle compartment on the control panel. Hazardous voltage will cause severe injury or death. On the controller base box and automatic voltage regulator, do not touch the terminals for voltage and current measurement. Disconnect all power sources and disable the generator set before servicing.

Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death. Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause severe injury or death to utility personnel working on power lines.

Servicing the generator set when it is operating. Exposed moving parts will cause severe injury or death. Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

Hot Parts



Hot coolant and steam. Can cause severe injury or death.

Before removing the pressure cap, stop the generator set and allow it to cool. Then loosen the pressure cap to relieve pressure. Fill system before starting unit.



Hot engine and exhaust system. Can cause severe injury or death.

Do not work on the generator set until it cools.

Servicing the alternator. Hot parts can cause severe injury or death. Avoid touching the alternator field or exciter armature. When shorted, the alternator field and exciter armature become hot enough to cause severe burns.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Servicing the engine heater. Hot parts can cause minor personal injury or property damage. Install the heater before connecting it to power. Operating the heater before installation can cause burns and component damage. Disconnect power to the heater and allow it to cool before servicing the heater or nearby parts.

Servicing the engine oil pan heater. Heated components can cause severe injury. The oil pan heater will rapidly become hot when energized. Do not touch the oil pan heater while it is hot. Disconnect power to the engine oil pan heater and allow to cool before servicing it or nearby parts.

Notice

NOTICE

Canadian installations only. For standby service connect the output of the generator set to a suitably rated transfer switch in accordance with Canadian Electrical Code, Part 1.

NOTICE

Electrostatic discharge damage.
Electrostatic discharge (ESD)
damages electronic circuit boards.
Prevent electrostatic discharge
damage by wearing an approved
grounding wrist strap when handling
electronic circuit boards or integrated
circuits. An approved grounding wrist
strap provides a high resistance (about
1 megohm), not a direct short, to
ground.

This manual provides installation instructions for the Model 24RCLA, 30RCLA, and 38RCLC generator sets. Operation manuals are available separately. See Figure 1 for an illustration of the 24RCLA generator set.

Kohler strongly recommends that only factoryauthorized dealers install and service the generator.

Information in this publication represents data available at the time of print. Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual. Keep this manual with the equipment for future reference.




Figure 1 Model 24RCLA Generator Set

List of Related Materials

Figure 2 identifies related literature available for the generator sets covered in this manual. Only trained and qualified personnel should install or service the generator set.

Literature Type	Part Number
Specification Sheet, 24RCLA	G4-303
Specification Sheet, 30RCLA	G4-304
Specification Sheet, 38RCLC	G4-305
Operation Manual, Generator Set	TP-6905
Service Manual, Generator Set	TP-6907
Parts Catalog, 24RCL(A), 30RCL(A), 38RCLB(C) Generator Set	TP-6908
Operation Manual, KG2204/KG2204T Engine	TP-6901
Service Manual, KG2204/KG2204T Engine Mechanical	TP-6902
Service Manual, Engine ECM Diagnostics	TP-6903
Parts Catalog, KG2204/KG2204T Engine	TP-6904
Operation Manual, OnCue® Plus Generator Management System	TP-7006
Operation/Installation Manual, RXT ATS	TP-6807
Operation/Installation Manual, RDT ATS	TP-6345
Installation Instructions, Programmable Interface Module (PIM)	TT-1584
Installation Instructions, Load Shed Kit	TT-1609
Installation Instructions, 50 Amp Power Relay Modules for Load Management	TT-1646
Installation Instructions, OnCue Plus Wireless Kit	TT- 1790

Figure 2 Related Literature

Warranty Registration

Complete the startup and installation checklists supplied with the startup notification form. Complete and sign the startup notification form and register the unit using the Kohler online Warranty processing System.

TP-7202 6/22 Introduction 9

Service Assistance

For professional advice on generator power requirements and conscientious service, please contact your nearest authorized Kohler dealer.

- Visit the Kohler Co. website at KOHLERPower.com.
- Look at the labels and decals on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

Headquarters Europe, Middle East, Africa (EMEA)

Kohler EMEA Headquarters Netherlands B.V. Kristallaan 1 4761 ZC Zevenbergen The Netherlands

Phone: (31) 168 331630 Fax: (31) 168 331631

Asia Pacific

Power Systems Asia Pacific Regional Office Singapore, Republic of Singapore

Phone: (65) 6264-6422 Fax: (65) 6264-6455

China

North China Regional Office, Beijing

Phone: (86) 10 6518 7950 (86) 10 6518 7951

(86) 10 6518 7952 Fax: (86) 10 6518 7955

East China Regional Office, Shanghai

Phone: (86) 21 6288 0500 Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office Bangalore, India

Phone: (91) 80 3366208

(91) 80 3366231

Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office

Tokyo, Japan

Phone: (813) 3440-4515 Fax: (813) 3440-2727

10 Service Assistance TP-7202 6/22

1.1 Introduction

Review this entire section and the Safety Precautions before starting the installation procedure. The generator set specification sheet also contains data that may be required during the installation process.

The generator set and accessories must be installed by an authorized Kohler dealer or authorized representative. The installation must comply with the National Electrical Code (NEC), state, and local codes. For Canadian installations, refer to the Canadian Electrical Code (CEC).

Note: These instructions outline one procedure for installing the generator set. Local codes may require different procedures.

The generator set must be installed outdoors. The exhaust systems on enclosed units are designed for outdoor installation only.

Note: DO NOT install these generator sets inside a building.

Note: Install carbon monoxide (CO) detector(s) on each level of any building adjacent to a generator set. Locate the detectors to adequately warn the building's occupants of the presence of carbon monoxide.

Read and follow the safety precautions in this manual and observe the decals on the equipment. Refer to the diagrams and drawings in Section 4 for dimensions and electrical connections during the installation procedure. Read the entire installation procedure and obtain the accessories and tools needed before beginning installation. Perform the steps in the order shown.


To install optional accessories, follow the instructions provided with each kit.



Hazardous voltage. Backfeed to the utility system. Can cause property damage, severe injury, or death.

If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

Grounding electrical equipment. Hazardous voltage will cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.



The exhaust system must be leakproof and routinely inspected.

Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building. Never operate the generator set where exhaust gas could seep inside or be drawn into a potentially occupied building through windows, air intake vents, or other openings.

Carbon monoxide detectors. Carbon monoxide can cause severe nausea, fainting, or death. Install carbon monoxide detectors on each level of any building adjacent to the generator set. Locate the detectors to adequately warn the building's occupants of the presence of carbon monoxide. Keep the detectors operational at all times. Periodically test and replace the carbon monoxide detectors according to the manufacturer's instructions.

TP-7202 6/22 Section 1 Installation Instructions 11

Tools Required:

- Multimeter (for measuring voltage and current)
- Frequency meter (may be part of multimeter)
- Pressure gauge or manometer (for measuring fuel pressure)
- Torque wrench
- Wrenches
- Screwdrivers
- Socket wrenches or nut drivers
- Pliers
- Safety glasses or goggles
- Drill with bits and hole saw

Installer/Customer-Supplied Items:

- One BCI group 24 size 12-volt battery with a minimum rating of 630 cold cranking amps (CCA) at 0°F
- · Gravel or crushed stone
- Concrete mounting pad
- Cables and conduit
- Fuel supply line with shutoff valve and pipe sealant (provided by fuel supplier)
- Carbon monoxide (CO) detector(s)

Available Accessories:

- Batterv
- Battery heater
- Block heater
- Oil pan heater
- Flexible fuel lines
- Load management system
- Programmable Interface Module (PIM) See TT-1584 for installation instructions.

1.2 Lifting Generator Set



Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage.

Do not use lifting eyes. Lift the generator set using lifting bars inserted through the lifting holes on the skid.

The approximate weight of the generator set with enclosure is shown in Figure 1-1. Use equipment that is rated for the generator set's weight to lift the unit into place. Lift the enclosure and generator set together as one unit.

Model	Weight, kg (lb.)
24RCLA	572 (1260)
30RCLA	599 (1320)
38RCLC	621 (1370)

Figure 1-1 Approximate Weights

Insert lifting bars through the four holes in the mounting skid. The placement of the holes maintains balance during lifting. See Figure 1-2.

Follow these general precautions when lifting all generator sets and related equipment.

- Install proper size rigging at the skid lifting eyes providing a direct pull on the skid lifting eye. Make sure the rigging does not work as a pry bar lever against the lifting eye.
- **DO NOT** lift the generator set using the lifting eyes attached to the engine and/or alternator as these lifting eyes can not support the total weight of the generator set.
- **DO NOT** attach hoisting equipment to the enclosure. Insert lifting bars through the four holes in the mounting skid.
- Always protect cables, chains, and straps from sharp
- Use a spreader bar to prevent lifting cables from contacting the enclosure.

- Lifting should only be conducted by those trained and experienced in lifting and rigging to achieve a safe and effective lift. Consideration needs to be given to, but not necessarily limited to the following items:
 - o Weight and center of gravity of the equipment being lifted
 - Weight and center of gravity of the lifting device
 - Boom angles
 - Selection of rated rigging
 - Stability of lifting foundation
 - Wind and weather conditions
 - o Local or regional codes that may require or restrict types of rigging.

The dealer/lifting contractor should choose one of the following methods to lift the generator set depending upon the location circumstances and the generator set's weight and size.

Single Spreader Bar and Skid Lifting Bar Method

Refer to Figure 1-3.

Double Spreader Bar and Skid Lifting Bar Method

Refer to Figure 1-4.





Figure 1-2 Typical Enclosure with Lifting Holes



Single Spreader Bar and Skid Lifting Bar Figure 1-3 Method (enclosure not shown)




Figure 1-4 Double Spreader Bar and Skid Lifting Bar Method (enclosure not shown)

1.3 Location and Mounting

1.3.1 Location Factors

The manufacturer recommends mounting the generator set on concrete at ground level. For installations suspended above ground level, including roof installations, weight considerations are especially important. The building engineer must determine whether the structure can support the weight of the generator set.

The location of the generator set must:

- Support the weight of the generator set and related equipment such as batteries, radiators, and mounting pad(s). Keep in mind that the mounting pad weight may exceed the weight of the generator set.
- Meet applicable fire rating and other national, state, and local codes and standards.
- Minimize the risk that people will come into contact with hot generator set surfaces.
- Position the generator set over a noncombustible surface. DO NOT allow accumulation of combustible materials under or around the generator set.
- Permit vibration isolation to reduce noise and prevent damage.
- Not be subject to flooding.
- Allow safe expulsion of exhaust.
- Provide clearance for cooling air flow and access for service. See Figure 1-5 and the dimension drawings in Section 4 for required minimum clearances from obstructions and combustible materials.
- Minimize the risk of public or unauthorized access.

Notice

DO NOT locate the generator set near patios, decks, play areas, or animal shelters. Keep items such as lawn furniture, toys, sports equipment, and all combustible materials away from the generator set exhaust outlet.

Remind family members, children, and visitors to use caution near the generator set. Generator sets connected to automatic transfer switches start automatically during exercise periods and power outages. Some generator set components become hot when the generator set is running and remain hot for a time after the generator set shuts down.




Figure 1-5 Air Intake and Exhaust

1.3.2 Mounting Surface

Install the generator set on a single, level concrete mounting pad. This method provides maximum stability and ensures correct cooling air flow through the generator set. The recommended mounting pad dimensions are shown in the dimension drawings in Section 4.

Refer to the generator set dimension drawings for conduit and fuel-line placement.

1.3.3 Vibration Isolation

The generator set is equipped with neoprene vibration isolators. Connections between the generator set or its mounting base and any conduits or fuel lines must include flexible sections to prevent breakage and to isolate vibration.

1.3.4 Prepare Site

Install the generator set outdoors near the incoming gas service. The generator set location must allow easy access for maintenance and service. The required distance from a structure is dependent on state and local codes. See the dimension drawings in Section 4 for specific requirements for clearance on all sides of the generator set.

Plan the installation so that the exhaust outlets of the generator set are not directed toward the building or any openings where exhaust gas could be drawn into the building.

Install carbon monoxide detectors on each level of any building adjacent to the generator set. Locate the detectors to adequately warn the building's occupants of the presence of carbon monoxide.

- Obtain a building permit and contact your local utility companies to mark the locations of underground pipes and cables.
- 2. Prepare an area for mounting the generator set.
 - a. Clear all combustible materials, including plants and shrubs, building materials, and lawn furniture, from the areas near the exhaust outlets of the generator set.

- b. Spread a 76 mm (3 in.) thick layer of gravel to support the concrete mounting pad. For the mounting pad dimensions, see the generator set dimension drawing in Section 4.
- c. Lay a 100 mm (4 in.) thick concrete pad on the gravel layer. Include mounting bolts and stubups for the fuel supply and electrical conduit. See the dimension drawing in Section 4 for the mounting bolt and stub-up locations.

1.3.5 Mount the Generator Set

- Place the generator set on the concrete mounting pad. Secure the generator set with mounting bolts anchored in the concrete pad.
- Remove the shipping bracket, which is attached to the skid under the engine and labeled with a hang tag.
- Remove the enclosure doors and alternator-end panel to gain access to the junction box and other generator set components during installation. Remove the covers to access the AC and DC connection terminal blocks.

TP-7202 6/22 Section 1 Installation Instructions 15

1.4 Electrical System





Hazardous voltage. Will cause severe injury or death.

Disconnect all power sources before opening the enclosure.







Hazardous voltage. Moving parts. Will cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.

A WARNING



Hazardous voltage. Backfeed to the utility system.

Can cause property damage, severe injury, or death.

If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

Grounding electrical equipment. Hazardous voltage will cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Disconnecting the electrical load. Hazardous voltage will cause severe injury or death. Disconnect the generator set from the load by turning off the line circuit breaker or by disconnecting the generator set output leads from the transfer switch and heavily taping the ends of the leads. High voltage transferred to the load during testing may cause personal injury and equipment damage. Do not use the safeguard circuit breaker in place of the line circuit breaker. The safeguard circuit breaker does not disconnect the generator set from the load.

Before installing the generator set, provide for electrical connections through conduit to the transfer switch and other accessories for the generator set. Route DC leads in separate conduit from AC conductors. Carefully install the selected generator set accessories. Route wiring to the generator set through flexible connections. Comply with all applicable codes when installing a wiring system.

See the dimension drawings in Section 4 for the recommended stub-up location.

AC circuit protection. All AC circuits must include circuit breaker or fuse protection. The circuit breaker must be rated for a maximum of 125% of the rated generator set output current. The circuit breaker must open all ungrounded connectors.

The generator set is equipped with a factory-installed circuit breaker.

16 Section 1 Installation Instructions TP-7202 6/22

1.4.1 **Electrical Connections**

Several electrical connections must be made between the generator set and other components of the system for proper operation. Most field-installed accessory kits include installation instructions. Comply with applicable national, state, and local codes when installing a wiring system.

For Canadian installations, refer to the Canadian Electrical Code (CEC).

For customer-supplied wiring, select the wire temperature rating in Figure 1-6 based upon the following criteria:

- Select row 1, 2, 3, or 4 if the circuit rating is 110 amperes or less or requires #1 AWG (42.4 mm²) or smaller conductors.
- Select row 3 or 4 if the circuit rating is greater than 110 amperes or requires #1 AWG (42.4 mm²) or larger conductors.

Row	Temp. Rating	Copper (Cu) Only	Cu/Aluminum (Al) Combinations	Al Only
1	60°C (140°F) or 75°C (167°F)	Use No. * AWG, 60°C wire or use No. * AWG, 75°C wire	Use 60°C wire, either No. * AWG Cu, or No. * AWG Al or use 75°C wire, either No. * AWG Cu or No. * AWG Al	Use 60°C wire, No. * AWG or use 75°C wire, No. * AWG
2	60°C (140°F)	Use No. * AWG, 60°C wire	Use 60°C wire, either No. * AWG Cu or No. * AWG AI	Use 60°C wire, No. * AWG
3	75°C (167°F)	Use No. *† AWG, 75°C wire	Use 75°C wire, either No. *† AWG Cu or No. *† AWG AI	Use 75°C wire, No.*† AWG
4	90°C (194°F)	Use No. *† AWG, 90°C wire	Use 90°C wire, either No. *† AWG Cu or No. *† AWG AI	Use 90°C wire, No.*† AWG

The wire size for 60°C (140°F) wire is not required to be included in the marking. If included, the wire size is based on ampacities for the wire given in Table 310-16 of the National Electrical Code®, in ANSI/NFPA 70, and on 115% of the maximum current that the circuit carries under rated conditions. The National Electrical Code® is a registered trademark of the National Fire Protection Association, Inc.

Figure 1-6 Terminal Markings for Various Temperature Ratings and Conductors

[†] Use the larger of the following conductors: the same size conductor as that used for the temperature test or one selected using the guidelines in the preceding footnote.

1.4.2 Terminal Connector Torque

Use the torque values shown in Figure 1-7 or Figure 1-8 for terminal connectors. Refer to UL-486A, UL-486B, and UL-486E for information on terminal connectors for aluminum and/or copper conductors. Comply with applicable national, state, and local codes when installing a wiring system.

Note: If a connector has a clamp screw such as a slotted, hexagonal head screw with more than one means of tightening, test the connector using both applicable torque values provided in Figure 1-8.

Socket Size Across Flats, mm (in.)	Tightening Torque, Nm (in. lb.)
3.2 (1/8)	5.1 (45)
4.0 (5/32)	11.4 (100)
4.8 (3/16)	13.8 (120)
5.6 (7/32)	17.0 (150)
6.4 (1/4)	22.6 (200)
7.9 (5/16)	31.1 (275)
9.5 (3/8)	42.4 (375)
12.7 (1/2)	56.5 (500)
14.3 (9/16)	67.8 (600)

Note: For values of slot width or length not corresponding to those specified, select the largest torque value associated with the conductor size. Slot width is the nominal design value. Slot length is to be measured at the bottom of the slot.

Figure 1-7 Tightening Torque for Pressure Wire Connectors with Internal-Drive Socket-Head Screws

Wire Size for Unit Connection		Slot Head 4.7 mm	Slot Head 4.7 mm (No. 10) or Larger*				
AWG, kcm	nil (mm²)	Slot Width <1.2 mm (0.047 in.) Slot Length <6.4 mm (0.25 in.)			Oth Connec		
18-10	(0.82-5.3)	2.3 (20)	4.0 (35)	9.0	(80)	8.5	(75)
8	(8.4)	2.8 (25)	4.5 (40)	9.0	(80)	8.5	(75)
6-4	(13.3-21.2)	4.0 (35)	5.1 (45)	18.6	(165)	12.4	(110)
3	(26.7)	4.0 (35)	5.6 (50)	31.1	(275)	16.9	(150)
2	(33.6)	4.5 (40)	5.6 (50)	31.1	(275)	16.9	(150)
1	(42.4)	<u> </u>	5.6 (50)	31.1	(275)	16.9	(150)
1/0-2/0	(53.5-67.4)		5.6 (50)	43.5	(385)	20.3	(180)
3/0-4/0	(85.0-107.2)	<u> </u>	5.6 (50)	56.5	(500)	28.2	(250)
250-350	(127-177)		5.6 (50)	73.4	(650)	36.7	(325)
400	(203)		5.6 (50)	93.2	(825)	36.7	(325)
500	(253)		5.6 (50)	93.2	(825)	42.4	(375)
600-750	(304-380)		5.6 (50)	113.0	(1000)	42.4	(375)
800-1000	(406-508)		5.6 (50)	124.3	(1100)	56.5	(500)
1250-2000	(635-1016)		_	124.3	(1100)	67.8	(600)

^{*} For values of slot width or length not corresponding to those specified, select the largest torque value associated with the conductor size. Slot width is the nominal design value. Slot length is to be measured at the bottom of the slot.

Note: If a connector has a clamp screw such as a slotted, hexagonal head screw with more than one means of tightening, test the connector using both applicable torque values.

Figure 1-8 Tightening Torque for Screw-Type Pressure Wire Connectors

Ground and Neutral Connections 1.4.3

Ground the generator set. The grounding method must comply with NEC and local codes. Connect the ground to the generator set ground lug, terminal GRD inside the junction box (see Figure 1-11). Connect the grounds for utility and low voltage connections to the ground lugs provided in the customer connection box for those specific connections (see Figure 1-11).

Various regulations and site configurations including the National Electrical Code (NEC), local codes, and the type of transfer switch used in the application determine the grounding of the neutral at the alternator. NEC 2002 Section 250.20 is one example that has a very good explanation of the neutral grounding requirements for generator sets.

Generator sets are shipped with the generator set neutral attached to the alternator in the junction box. At installation, the neutral can be grounded at the generator set or lifted from the ground stud and isolated if the installation requires an ungrounded neutral connection at the alternator. The generator set will operate properly with the neutral either bonded to ground or isolated from ground at the alternator.

1.4.4 **Battery Chargers**

An engine-driven, battery-charging alternator charges the battery whenever the generator set operates. Engine-driven systems can quickly restore the charge used in a normal cranking cycle.

When the engine is not operating, a very low charge rate from an AC-powered battery charger is usually sufficient to maintain a full charge on the batteries. The RDC2 controller contains a built-in battery charger to maintain the generator set's engine starting battery. Be sure to provide AC power for the integral battery charger as instructed in Section 1.4.5.

1.4.5 **Power Supply**

Power must be supplied to the generator set location for the battery charger and optional accessories. The power source must comply with both state and local codes. The power to the accessories must be available at all times, i.e. the circuit must be powered by the utility source and backed up by the generator set. See Figure 1-9 for the power requirements for the battery charger and accessories.

Connect power to the leads in the utility power connection area shown in Figure 1-11. This connection provides power for charging the engine starting battery. See the wiring diagrams in Section 4 for connection details.

For other AC accessories such as engine heaters, install an AC receptacle near the generator set.

	Power Requirement				
Equipment	Watts	Amps	Volts		
Battery charger (standard, integral to RDC2 controller)	50	0.42	120		
Oil pan heater (optional)	150	1.25	120		
	150	0.63	240		
Battery heater (optional)	80	0.7	120		
Block heater (optional)	500	4.2	120		
	500	2.1	240		

Figure 1-9 Power Requirements

1.4.6 Connect AC and DC Wiring

Note: Have a licensed electrician make the following electrical connections. All connections must comply with state and local codes.

Size the wire according to the length of run and 115% of the circuit current (amperage) based on 75°C wire rating or less as directed by the National Electrical Code® (NEC) in ANSI/NFPA 70. See Section 1.4.1 for additional information about wire selection.

The generator set is equipped with a field-connection terminal block located in the access area below the junction box. Leads have been factory-installed from the junction box to the terminal block for easy field wiring.

See Figure 1-11. Make all AC and DC customer connections inside the customer connection box. Do not remove the upper panel or make connections inside the upper area of the junction box. Refer to the wiring diagrams in Section 4.

Load Circuit Breaker Connections

Figure 1-10 load connection torque specifications.

Model	Frequency, Voltage	Breaker Description	Torque, Nm (in. lbs.)
24RCLA	60Hz, 120/240V, 1Ph, 3W	100 Amp, 2- Pole	5.6 (50)
	60Hz, 120/208V, 3Ph, 4W, Wye	90 Amp, 3- Pole	8.5 (75)
	60Hz, 127/208V, 3Ph, 4W, Wye	90 Amp, 3- Pole	8.5 (75)
	60Hz, 120/240V, 3Ph, 4W, Delta	80 Amp, 3- Pole	8.5 (75)
	60Hz, 277/480V, 3Ph, 4W, Wye	40 Amp, 3- Pole	9- 10.2 (80- 90)
	50Hz, 230/400V, 3Ph, 4W, Wye	40 Amp, 3- Pole	9- 10.2 (80- 90)
30RCLA	60Hz, 120/240V, 1Ph, 3W	150 Amp, 2- Pole	8.5 (75)
	60Hz, 120/208V, 3Ph, 4W, Wye 125 Amp, 3- Pole		9- 10.2 (80- 90)
	60Hz, 127/208V, 3Ph, 4W, Wye	100 Amp, 3- Pole	5.6 (50)
	60Hz, 120/240V, 3Ph, 4W, Delta	100 Amp, 3- Pole	5.6 (50)
	60Hz, 277/480V, 3Ph, 4W, Wye	50 Amp, 3- Pole	9- 10.2 (80- 90)
	50Hz, 230/400V, 3Ph, 4W, Wye	60 Amp, 3-Pole	9- 10.2 (80- 90)
38RCLC	60Hz, 120/240V, 1Ph, 3W	175 Amp, 2- Pole	8.5 (75)
	60Hz, 120/208V, 3Ph, 4W, Wye	150 Amp, 3- Pole	9- 10.2 (80- 90)
	60Hz, 127/208V, 3Ph, 4W, Wye	125 Amp, 3- Pole	9- 10.2 (80-90)
	60Hz, 120/240V, 3Ph, 4W, Delta	125 Amp, 3- Pole	9- 10.2 (80- 90)
	60Hz, 277/480V, 3Ph, 4W, Wye	60 Amp, 3-Pole	9- 10.2 (80- 90)
	50Hz, 230/400V, 3Ph, 4W, Wye	60 Amp, 3-Pole	9- 10.2 (80- 90)

Figure 1-10 Load Circuit Breaker Hardware Torque Recommendations




Figure 1-11 Generator Set Connections

Generator Set Connections

Use separate conduit for the power cables and the low voltage communication or engine start leads. Local codes and the length of run as well as the transfer switch wire size requirements will determine the wire size needed for the AC leads.

Note: Some codes require the use of a disconnect switch. Check the code requirements for your location and install a disconnect switch, if required.

- 1. Route the load leads into the junction box through the access opening in the bottom of the box. Connect the load leads from the line circuit breaker in the generator set junction box to the transfer switch emergency power connection points. See Figure 1-11 and refer to transfer switch installation manual for ATS connection instructions.
- 2. Connect the neutral (L0) and ground (GRD) leads from the ATS and the main panel to the corresponding lugs in the connection box. See Section 1.4.3 for grounding information.
- 3. Cut or punch openings in the side of the connection box for the 120 VAC power supply leads and the low voltage connections. See Figure 1-11. Use separate conduit for the power leads and the low voltage leads.
- 4. Connect utility power for the controller's battery charger and GFCI outlet. Connect to a circuit that is supplied by the utility source and backed up by the generator. See Section 1.4.5 and Figure 1-11 for more information about the utility power requirement.
- 5. For transfer switch communication and/or engine start connection, see Section 1.4.7.
- 6. For connection of the optional programmable interface module (PIM), and/or a load shed kit, see Section 1.4.9.
- 7. Install an AC receptacle for the AC accessories, if equipped. Power to this receptacle must be available when the generator set is not running. See Figure 1-9 for accessory power requirements.

- 8. To connect the OnCue® Plus Generator Management System to your generator, run network cable from the generator set to the customer's router or modem.*
 - a. Route the network cable with other low-voltage signal wiring (for example, the RBUS communication leads or engine start leads to the transfer switch), in separate conduit from the AC load leads. If the network cable is longer than 100 meters (328 ft.), use a repeater or switch.
 - b. Test the Internet connection for the generator by connecting a laptop to the network cable.
 - (1) Turn OFF any wireless connections to the laptop.
 - (2) Connect the network cable to the laptop. Connect the other end of the network cable to the customer's router or modem.
 - (3) Verify the Internet connection by opening your web browser and going to www.kohlerpower.com or any known website.
 - (4) Disconnect the network cable from the laptop.
 - c. Use an RJ45 inline coupler to connect the Ethernet cable to the cable in the customer connection box. The inline coupler is included with the OnCue Plus kit.
- * If the OnCue Plus Wireless Kit is being used, refer to the Installation instructions provided with the wireless kit.

1.4.7 Automatic Transfer Switch Connection



Hazardous voltage. Backfeed to the utility system. Can cause property damage, severe injury, or death.

If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

A typical standby system has an automatic transfer switch connected to the generator set output to automatically transfer the electrical load to the generator set if the normal source fails. The normal power source is typically utility power. When normal power returns, the switch transfers the load back to the normal power source and then signals the generator set to stop.

Connect the ATS or remote start/stop switch. Connect the load leads from the generator set to the Emergency source lugs on the ATS. Connect the RBUS or engine start connections as described below. Route low-voltage communication leads through separate conduit from the AC power and load leads. All connections must comply with applicable state and local codes.

Kohler Model RXT Automatic Transfer Switch

The RDC2 controller is designed to control the Kohler Model RXT transfer switch as well as the generator set.

Follow the installation instructions to connect the transfer switch interface board to the appropriate terminals on the generator set. The RDC2 controller uses a Kohler-proprietary communication protocol to communicate with the transfer switch.

When connected to a Kohler Model RXT transfer switch, the RDC2 controller provides the following features:

- Monitors and displays utility voltage and frequency.
- Schedule loaded exercises from the RDC2 generator set controller.
- Set the ATS system voltage and frequency.
- Allows calibration of the utility voltage and frequency at the generator set controller.
- Allows adjustment of transfer switch transfer time delays from the generator set controller.

RBUS communication connections for a Kohler® Model RXT transfer switch

One Model RXT transfer switch can be connected to the generator set. See Figure 1-12. Use shielded, twisted-pair cable to connect P10-1 through P10-4 on the transfer switch interface module to the generator set terminal block connections A, B, PWR, and COM. See Section 1.4.8 for communication cable recommendations and maximum cable length.

The Model RXT transfer switch with the combined interface/load management board requires one set of RBUS connections to the generator set. However, the combined board acts as two RBUS modules: one RXT transfer switch and one load management device.

Note: Connections 3 and 4 on the generator set are not used with the Model RXT transfer switch.

22 Section 1 Installation Instructions TP-7202 6/22




Figure 1-12 Model RXT Transfer Switch Communication Connection to Generator Set Terminal Block

TP-7202 6/22 Section 1 Installation Instructions 23

Engine start connection for other transfer switches or a remote start/stop switch

Note: Do not use the Kohler® Model RRT transfer switch with Model RCL generator sets.

Other Kohler transfer switches, including Model RDT or Model K (MPAC™) transfer switches can be used with the Kohler generator sets covered in this document. These transfer switches contain separate ATS controls that do not communicate with the RDC2 controller.

These transfer switches use a set of contacts to signal the engine/generator to start. When the normal source fails and the generator set is in AUTO mode, the transfer switch contacts close to signal the generator set to start and run. After the normal source returns, the contacts open to signal the generator set to stop.

The engine start terminals are usually located near the transfer switch contactor with an engine start decal identifying the terminals. Use the transfer switch wiring diagrams to identify the engine start terminals prior to making connections.

Connect the transfer switch engine-start contacts or a remote manual engine-start switch to the engine start terminals (3 and 4) on the generator set. Size the wire according to the transfer switch connection and the length of run. Use separate conduit for the DC engine-start leads and the AC generator set load cables and battery charger leads.

See Figure 1-13. Connect the engine start leads from the transfer switch or remote start switch to terminals 3 and 4 on the terminal block. Route the engine start leads through separate conduit from the AC power and load leads.

Close the remote start contacts to start and run the generator set. Open the contacts to signal the generator set to stop. The generator set controller must be in AUTO mode for remote start/stop.




Figure 1-13 Engine Start Connections with Transfer Switch Models other than Model RXT

Communication Cable 1.4.8 **Specifications**

RBUS Connections A and B

For the RBUS communication connections A and B to the optional RBUS modules, use 20 AWG shielded, twisted-pair communication cable. Belden #9402 (two-pair) or Belden #8762 (single-pair) or equivalent cable is recommended. Optional RBUS modules can include the Model RXT transfer switch, RXT combined interface/load management board. automatic paralleling module (APM), programmable interface module (PIM), and/or the load shed kit for the RDT or RXT transfer switch.

For outdoor installations, including those with buried cables and/or conduit, use outdoor-rated Belden #1075A or equivalent 20 AWG shielded, twisted-pair communication cable.

PWR and COM Connections

For the PWR and COM connections, the cable size and maximum cable length depends on the number of modules connected. See Figure 1-14.

- For short cable runs shown in the first two rows of Figure 1-14, use one pair in the two-pair communication cable for the A and B connections, and use the second pair for the PWR and COM connections.
- For the longer cable runs shown in the last two rows of Figure 1-14, use 12 or 14 AWG cable for PWR and COM, and use the 20 AWG communication cable specified above for the A and B connections only. In this case, single-pair communication cable such as Belden #8762 can be used for the A and B connections.

Note: A model RXT transfer switch with combined interface/load management board acts as two RBUS modules: one RXT transfer switch and one load management device.

Note: Power relay modules, if used, are not RBUS modules and do not have RBUS communication connections.

	Maximum length per run, meters (ft.)							
Number of Modules per Run (RXT, APM, PIM, and/or load management device)								
Cable (TB1 PWR and COM)	1 Module	2 Modules	3 Modules	4 Modules				
Belden #9402 or equivalent 20AWG for indoor installation	46 (150)	15 (50)	5 (17)	Do not use 20AWG for PWR and COM				
Belden #1075A or equivalent 20AWG for outdoor installations or buried cables	46 (150)	15 (50)	5 (17)	Do not use 20AWG for PWR and COM				
14 AWG *	137 (450)	137 (450)	107 (350)	107 (350)				
12 AWG *	137 (450)	137 (450)	137 (450)	137 (450)				

^{*} Use 12 or 14 AWG cable for PWR and COM connections only. For RBUS connections A and B, use shielded, twisted pair communication cable specified above.

Figure 1-14 Total Cable Lengths for PWR and COM Connections

1.4.9 System Connections with Accessory Modules

See Figure 1-15 through Figure 1-18 for connection options with up to three accessory modules. Accessory modules can include one Model RXT transfer switch,

one programmable interface module (PIM), and/or one load control module (load shed kit).

See Section 1.4.8 for cable size and length specifications.




Figure 1-15 Accessory Module Communication Connection Details

5. Leave the end of each cable shield disconnected at the last device.




Figure 1-16 Accessory Module Connections with 12-14 AWG Power Leads (one cable run with three modules shown)

TP-7202 6/22 Section 1 Installation Instructions 27




Figure 1-17 Multiple Connections to the Generator Set




Figure 1-18 Accessory Module Connections (two cable runs with one and two modules shown)

1.4.10 Other Accessories

See Section 2 for information about available accessories.

Install and connect optional accessories. Follow the installation instructions provided with the accessory kits.

1.5 Engine Starting Battery

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

WARNING



Explosion.

Can cause severe injury or death. Relays in the battery charger cause arcs or sparks.

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation or maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Use a BCI group 24 size 12-volt battery with a minimum rating of 630 cold cranking amps (CCA) at 0°F.

- 1. Ensure that the starting battery is fully charged before placing the battery in service.
- 2. Clean the battery posts and/or adapters if necessary.
- 3. Install battery post adapters, if needed.
- See the dimension drawing in Section 4 for the battery rack location. Place the battery on the battery rack on the skid.
- 5. Connect the red battery cable to the positive (+) battery terminal.
- 6. Connect the black battery cable to the negative (-) battery terminal.
- 7. Place the boots over the battery terminals.

When power is applied to the RDC2 controller (that is, when the battery is connected), you will be prompted to set the date and time, and then to set the exerciser. See Section 1.9 and the generator set operation manual for instructions.

If the battery is disconnected for service or replacement, the exercise settings on the RDC2/DC2 controller are lost. Set the exerciser after installing and connecting the battery. See Section 1.9, Set Exerciser.

1.6 Fuel System



Explosive fuel vapors.
Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

The fuel system. Explosive fuel vapors can cause severe injury or death. Vaporized fuels are highly explosive. Use extreme care when handling and storing fuels. Store fuels in a well-ventilated area away from spark-producing equipment and out of the reach of children. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks. Do not smoke or permit flames or sparks to occur near sources of spilled fuel or fuel vapors. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines. Use flexible sections to avoid fuel line breakage caused by vibration. Do not operate the generator set in the presence of fuel leaks, fuel accumulation, or sparks. Repair fuel systems before resuming generator set operation.

Gas fuel leaks. Explosive fuel vapors can cause severe injury or death. Fuel leakage can cause an explosion. Check the LPG vapor or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6-8 ounces per square inch (10-14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

Explosive fuel vapors can cause severe injury or death. Take additional precautions when using the following fuels:

Propane (LPG)—Adequate ventilation is mandatory. Because propane is heavier than air, install propane gas detectors low in a room. Inspect the detectors per the manufacturer's instructions.

Natural Gas—Adequate ventilation is mandatory. Because natural gas rises, install natural gas detectors high in a room. Inspect the detectors per the manufacturer's instructions.

Gas fuel systems operate on either LP vapor or natural gas. Refer to the generator set specification sheet and Section 1.6.3 for more detailed information on fuel requirements.

Note: The fuel system installation must comply with the National Electrical Code® (NEC) and applicable local codes.

30 Section 1 Installation Instructions TP-7202 6/22

Fuel Lines 1.6.1

Gas lines. Never use fuel piping to ground electrical equipment. The gas supplier is responsible for installation, repair, and alteration to gas piping.

Use Schedule 40 black-iron pipe for gas piping. Copper tubing may be used if the fuel does not contain hydrogen sulfide or other ingredients that react chemically with copper.

Line size. Size piping according to the requirements of the equipment. The type of fuel, the distance it must travel from gas meter/tank to fuel shutoff solenoid, and the amount consumed by the engine must be considered when determining fuel line pipe size.

In addition to actual fuel consumption, consider the following pressure loss factors:

- Pipe length
- Other appliances on the same fuel supply
- Number of fittings

Measure the pipe length from the primary gas pressure regulator to the pipe connection on the generator set fuel inlet. Add 2.4 m (8 ft.) to the measured length for each 90 degree elbow. Use the pipe size indicated in Figure 1-19 for the total length of pipe.

Figure 1-19 is based on gas pressures of 3.4 kPa (0.5 psi, 13.8 in. water column) or less and a pressure drop of 0.12 kPa (0.018 psi, 0.5 in. water column) with a 0.60 specific gravity and with a normal amount of restriction from fittings. The LPG flow has been corrected for specific gravity to determine the pipe sizes shown in the table.

Flexible connections. Rigid mount the piping but protect it from vibration. Use flexible connections spanning a minimum of 152 mm (6 in.) between the stationary piping and the engine fuel inlet connection.

	Maximum Fuel Flow			Nominal Iron Pipe Size, in.							
		Rate@ F		Pipe Length, m (ft) *							
Model	Fuel	cfh	LPG cfh corrected	3.0 (10)	6.1 (20)	12.2 (40)	18.3 (60)	24.4 (80)	30.5 (100)	45.7 (150)	61.0 (200)
04DCLA	LPG	113	179	1	1	1	1	1	1 1/4	1 1/4	1 1/4
24RCLA	NG	301	NA	1	1	1	1 1/4	1 1/4	1 1/4	1 1/4	1 1/2
000001.4	LPG	166	262	1	1	1	1 1/4	1 1/4	1 1/4	1 1/4	1 1/4
30RCLA	NG	424	NA	1	1	1 1/4	1 1/4	1 1/4	1 1/2	1 1/2	1 1/2
000010	LPG	197	311	1	1	1	1 1/4	1 1/4	1 1/4	1 1/2	1 1/2
38RCLC	NG	492	NA	1	1 1/4	1 1/4	1 1/2	1 1/2	1 1/2	2	2
* Add 2.4 m	(8 ft.) to th	e measured le	ngth for each 90	degree ell	oow.	•		•	•	•	

Figure 1-19 Fuel Pipe Sizes

1.6.2 Gas Regulators

Gas regulators reduce high incoming fuel pressures to lower levels acceptable for engines. See the generator set specification sheet for fuel supply pressure requirements.

Primary gas regulator. The primary regulator reduces the high pressure from a tank or transmission line to the lower pressure required by the secondary regulator on the engine. The fuel supplier provides the primary regulator. The fuel supplier is also responsible for providing sufficient gas pressure to operate the primary regulator.

Secondary gas regulator. The secondary regulator is factory-installed on the generator set engine and controls the inlet pressure to the engine.

1.6.3 Install and Connect Fuel Supply

Note: Have the fuel piping and regulator installed by the fuel supplier. The fuel supply installation must comply with NEC and local codes.

- See the generator set spec sheet for the fuel supply requirements. Add up the fuel requirements for the generator set plus all other gas-fired equipment fueled by the same supply.
- Check that the primary regulator and gas meter have sufficient capacity for the fuel requirements for the generator set plus all other gas-fired equipment. Have the fuel supplier install a larger gas meter, if necessary.
- 3. Determine the fuel pipe size as described in Section 1.6.1.
- Have your fuel supplier install a manual fuel shutoff valve and rigid gas piping. Bring the pipe to within 254 mm (10 in.) of the generator set fuel inlet location.
- 5. Remove the enclosure door on the service side of the unit.

- 6. Connect the fuel supply:
 - a. Apply pipe sealant that is approved for fuel connections to the threaded fuel connections.
 - b. Use a section of flexible fuel line to connect the fuel supply to the 1 in. NPT fuel inlet connection on the generator set. See Figure 1-20 or the dimension drawing in Section 4 for the fuel inlet connection location.
 - c. Open the manual fuel valves and leak test all fuel connections using soapy water. If a leak is detected, close the fuel valves, disconnect the lines at the location of the leak, clean the fittings, and apply fresh pipe sealant. Reconnect the lines and recheck for leaks.
- 7. Verify that the fuel system is set up for the fuel being used (natural gas or LPG). See Section 1.6.4.

Note: After the system installation is complete, check for fuel leaks with the generator set running.




Figure 1-20 Fuel Supply Connection Location (30RCLA generator set shown)

32 Section 1 Installation Instructions TP-7202 6/22

1.6.4 Fuel Conversion Procedures

The generator set is easily configurable for use with either NG or LPG. System configuration for NG or LPG requires a mechanical setting on the fuel pressure regulator and an electrical connection on the wiring harness. These adjustments will ensure that the proper fuel and spark timing are supplied to the engine.

Note: The fuel pressure regulator is factory preset for NG. When using NG, no mechanical adjustment is required.




Figure 1-21 Fuel Pressure Regulator

To set the regulator for LPG:

- 1. Push the adjusting cap to its upper stop and rotate toward the LPG marking, release upward pressure, and lock into place. Figure 1-21.
- For LPG fuel only, use the quick-connect adapters to connect wire N20 from the fuel pressure regulator to wire 45 from the ECM wiring harness. Figure 1-22.

To reset the regulator for NG:

Reverse the above procedure to reset for NG operation.

- Push up on the adjusting cap and rotate toward the NG marking. Release upward pressure, and lock into place. Figure 1-21.
- 2. Disconnect wire N20 and wire 45. Figure 1-22.




Figure 1-22 Fuel Type Connections

Converting the fuel will change the generator set rating. See the generator set specification sheet for ratings with natural gas and LPG. Order a new nameplate with the updated rating and fuel information from an authorized dealer, if necessary. Provide the following information from the original nameplate:

- Model Number
- kVA
- Spec Number
- Amps
- Serial Number
- Volts
- Fuel (original and new)
- Hz

kW

Attach the new nameplate over the old one. Do NOT cover the UL listing information on the old nameplate.

1.7 Cooling System



Hot coolant and steam.
Can cause severe injury or death.

Before removing the pressure cap, stop the generator set and allow it to cool. Then loosen the pressure cap to relieve pressure. Fill system before starting unit.

The generator set is equipped with a unit-mounted radiator common cooling system. Add coolant before starting the generator set.

The system's major components include two electric fans, a circulating water pump, a radiator, and a thermostat. The pump circulates water through the engine until it reaches operating temperature. Then the engine thermostat opens, allowing water circulation through the radiator. The thermostat restricts water flow as necessary to prevent overcooling. The fans blow air through the radiator across the cooling surface.

On models 30RCLA and 38RCLC only, an oil cooler provides additional cooling and is located at the bottom of the radiator. As engine oil passes through the oil cooler, coolant from the radiator circulates around the oil cooler removing heat. (The oil cooler is not used on model 24RCLA.)

Some generator sets are equipped with an optional block heater.

Note: Block Heater Damage. The block heater will fail if the energized heater element is not immersed in coolant. Fill the cooling system before turning on the block heater. Run the engine until it is warm, and refill the radiator to purge the air from the system before energizing the block heater.

Follow the instructions below to fill the cooling system.

1. Close the radiator's coolant drain valve and tighten the hose clamps.

Note: Do not add coolant to a hot engine. Adding coolant to a hot engine can cause the cylinder block or cylinder head to crack. Wait until the engine has cooled.

2. Fill the radiator with the recommended coolant mixture of 50% ethylene glycol-based long-life coolant and 50% clean, softened water to inhibit rust/corrosion and prevent freezing. See Figure 1-23 for the engine coolant capacity and Figure 1-24 for coolant fill location. Do not replace the pressure cap at this time.

Note: A coolant solution of 50% ethylene glycol provides freezing protection to -37°C (-34°F) and overheating protection to 149°C (300°F). A coolant solution with less than 50% ethylene glycol may not provide adequate freezing and overheating protection. A coolant solution with more than 50% ethylene glycol can cause engine or component damage. Do not mix long-life coolant and conventional coolants. Do not use alcohol or methanol antifreeze or mix them with the specified coolant.

- 3. Check the oil level before operating the engine.
- Operate the engine with the radiator's pressure cap removed until the thermostat opens and the radiator upper hose becomes hot.
- 5. Stop the engine and allow it to cool.
- 6. Add coolant to the radiator to just below the overflow tube on the filler neck. See Figure 1-24.
- 7. Replace the radiator's pressure cap.
- 8. Maintain the coolant level in the coolant overflow bottle between the Hot and Cold markings. See Figure 1-24 for the coolant overflow bottle location.

	Coolant Capacity, L (gal.)	
Model	Engine	Engine with Block Heater
24RCLA, 30RCLA, 38RCLC	13.2 (3.5)	13.7 (3.6)

Figure 1-23 Coolant Capacity (approximate)




Figure 1-24 Coolant Fill (24RCLA shown)




Figure 1-25 Coolant Fill (30RCLA and 38RCLC shown)

1.8 Prestart Installation Check

Review the entire installation section. Inspect all wiring and connections to verify that the generator set is ready for operation. Check all items in the following Prestart Checklist.

Prestart Checklist

Air Cleaner. Check that a clean air cleaner element is installed to prevent unfiltered air from entering the engine. See the generator set operation manual for instructions.

Air Inlets. Check for clean and unobstructed air inlets.

Battery. Check for tight battery connections. Consult the battery manufacturer's instructions regarding battery care and maintenance.

Coolant Level. Check the coolant level as described in Section 1.7.

Note: Block Heater Damage. The block heater will fail if the energized heater element is not immersed in coolant. Fill the cooling system before turning on the block heater. Run the engine until it is warm, and refill the radiator to purge the air from the system before energizing the block heater.

Enclosure. Check that all enclosure panels and internal baffling are in place.

Oil Level. Maintain the oil level at or near, not over, the full mark on the dipstick.

Operating Area. Check for obstructions that could block the flow of cooling air. Keep the air intake area clean. Do not leave rags, tools, or debris on or near the generator set.

TP-7202 6/22 Section 1 Installation Instructions 35

1.9 Set Exerciser

When power is applied to the RDC2 controller (that is, when the battery is connected), you will be prompted to set the date and time, and then to set the exerciser. Set the exerciser to automatically run the generator set on the desired day and time every week or every two weeks.

Figure 1-26 shows the controller screens. The first setting will flash. Press the Up and Down arrow buttons to change the setting. Press Select to save the setting and move on to the next. Repeat until the date, time, and exercise are set and the controller display shows the main menu. See TP-6905, Generator Set Operation Manual, for more detailed instructions to set the date and time and set the exerciser.





Figure 1-26 Set Date, Time, and Exercise, RDC2
Controller

In order to set a loaded exercise using the RDC2 controller, a Kohler® Model RXT transfer switch must be connected. To set a loaded exercise on a generator set connected to a transfer switch other than a Model RXT, use the transfer switch controller to set the exercise. Refer to the transfer switch operation manual for instructions.

The controller must be in automatic mode for the exerciser to operate as scheduled. Press AUTO to place the generator set controller into automatic mode.

1.10 Operation Tests



- 1. Verify that all guards are in place. Install the enclosure's end panels and nonservice side door.
- 2. Check the items in the Prestart Checklist in the generator set operation manual.
- Set the time and date, and then set the exerciser to run the generator set once a week or every other week to keep the generator set in good operating condition. See TP-6905, Operation Manual, for instructions to set the date and time and set the exerciser.
- 4. Press the RUN button on the generator set controller to start the generator set.
- Use a digital voltmeter (DVM) to check the output voltage from the generator set. If voltage calibration is required, refer to Section 3.5 for instructions.
- 6. Press OFF to stop the engine. Then press AUTO on the RDC2 controller.
- Install the enclosure's service-side door. Verify that all enclosure doors and panels are installed. Lock the enclosure doors to prevent unauthorized access.

Section 1 Installation Instructions TP-7202 6/22

1.11 OnCue Plus Generator **Management System**

The OnCue® Plus Generator Management System is included with model 24RCLA, 30RCLA, and 38RCLC generators. OnCue Plus allows monitoring and control of your generator set from a personal computer, smart phone, or tablet. OnCue Plus can also be configured to send email or text message notifications in the event of a generator set fault. See G18-247, Quick Start Guide and TP-7006, OnCue Plus Operation Manual, for instructions.

To use OnCue Plus, you must have the following minimum requirements for connecting your generator to the Internet:

- "Always-on" Internet service for generator set connection (for example, cable, DSL, or phone line modem connected 24 hours)
- Unused Ethernet port on a switch, router, or modem
- An uninterruptible power supply (UPS) for the modem and router is recommended.
- 5E customer-supplied network cable for connection of the generator set to the customer's Ethernet router OR optional OnCue Plus Wireless kit (see installation instructions in Section 1.4.6)
- USB cable, male USB A to male mini-B, for updating the controller firmware.

For instructions on connecting the network cables to the generator set, see instructions in Section 1.4.6.

Instructions to install the OnCue Plus Wireless Kit are included with the kit.

Notes

38 Section 1 Installation Instructions TP-7202 6/22

2.1 Introduction

Obtain the most current list of accessories from the generator set specification sheet or by contacting an authorized Kohler dealer. Have accessories installed by your local authorized Kohler dealer or authorized representative. Follow the installation instructions provided with each kit.

Use separate conduit for AC and DC leads to reduce the possibility of electrical interference. Use shielded cable for all analog inputs. Verify that the leads and conduit do not interfere with the operation of the generator set or obstruct the service areas.

Refer to the wiring diagrams in Section 4 for more information regarding generator set electrical connections and conduit/stub- up locations.

Verify that the accessory installation complies with the National Electrical Code (NEC) and all applicable local and state codes.

The following sections detail a few common accessories and their functions. The instructions provided with the accessory kit supersede these instructions, if different.

2.2 Battery Heaters

The battery heater kit includes a heating battery wrap to help increase the battery temperature in cold climates and a thermostat for controlled heating. The heater requires a 120 VAC, 15 amp. electrical outlet within reach of the power cord for each battery heater wrap.

Note: Battery heaters are compatible with all Kohler-supplied lead-acid batteries.* For other battery types, check the battery manufacturer's instructions for any restrictions regarding the use of battery heaters.




Figure 2-1 Typical Battery heater

TP-7202 6/22 Section 2 Accessories 39

2.3 Emergency Stop Kits

The emergency stop (E-stop) switch allows immediate shutdown of the generator set from a remote location. The E-stop assembly includes a shroud that allows the installation of a lockout/tagout device to lock the switch in the stop position. See Figure 2-2. Mount the emergency stop switch(es) outside of the generator set enclosure, in accordance with NEC requirements.

When the emergency stop switch is activated, contacts in the switch open to shut down the generator set. Connect as many emergency stop switches as required. Connect multiple switches in *series* to ensure that activating any one of the stop switches will stop the generator set.




Figure 2-2 Emergency Stop Switches

2.4 Load Management

Two optional load management devices are available for use with single-phase generator sets and a model RXT or RDT transfer switch. Choose one of these two options:

- The optional Load Shed Kit mounts inside a model RDT or RXT transfer switch. Figure 2-3 shows the load shed assembly.
- The combined interface/load management board is available for the Model RXT transfer switch.

The devices provide an automatic load management system to comply with Section 702.5 of NEC 2008.

Note: The load management devices are only compatible with single-phase generator sets.

With a load management system, less critical appliances can be powered by the generator set when the more important appliances are not running, allowing the use of a smaller generator set than would be needed to run all of the building's electrical equipment at the same time.

The load management device automatically manages up to six residential loads.

- Two relays are included to control two independent heating, ventilation, and air conditioning (HVAC) loads.
- Up to four power relay modules can be connected through normally open relay contacts on the circuit board. Power relay modules are available separately. See Section 2.4.1.

The load management device receives commands from the RDC2 or DC2 generator controller and energizes or de-energizes the appropriate load relays to add or shed non-critical loads according to their priority.

Note: Connect only non-essential loads to the load management device.

An adequate electrical supply is required for operation of the power relays connected to the load management device. Check the electrical requirements of the customer-provided equipment prior to installation to determine the wire size and circuit protection required. The installer is responsible for ensuring that the power system installation complies with all applicable state and local codes.

40 Section 2 Accessories TP-7202 6/22

For detailed installation and connection instructions, see TT-1609, provided with the load shed kit, or the Operation/Installation Manual for the Model RXT transfer switch with combined interface/load management board.




Figure 2-3 Load Shed Assembly (mounts inside the RDT or RXT transfer switch enclosure)

2.4.1 Power Relay Module

The power relay module kit contains one 50 amp relay with connecting lugs in a NEMA type 3R enclosure. Connect up to four (4) power relay modules to the load management devices listed above.

The power relay modules can be mounted indoors or outdoors. Two (2) 120 VAC loads (shed simultaneously) or a single 240 VAC load can be wired to each relay.

For detailed installation and connection instructions, see TT-1646, provided with the power relay module kit.



Figure 2-4 Power Relay Module

2.5 OnCue Plus Wireless Kit

The OnCue® Plus Wireless Kit allows connection of residential/light commercial generator sets to the customer's Internet router without running a network cable from the customer's computer router to the generator set. Use this kit to connect the generator set to the Internet for the Kohler® OnCue® Plus Generator Management System.

The kit uses two wireless bridges that communicate with each other. One wireless bridge is installed inside the generator enclosure and powered by the generator's engine starting battery. The second wireless bridge is installed near the customer's router and connected to 120 VAC power.




Figure 2-5 Wireless Bridge (kit includes qty 2; mounting location may vary)

TP-7202 6/22 Section 2 Accessories 41

2.6 Programmable Interface Module (PIM)

The optional Programmable Interface Module (PIM) provides two programmable inputs and six dry contact outputs, four of which are programmable. The PIM with enclosure is shown in Figure 2-6. See TT-1584 for PIM installation and connection instructions.

The PIM is typically mounted in a NEMA 3R aluminum enclosure, which can be mounted indoors or outdoors. On the 24RCLA, the PIM may be factory-installed inside the generator set junction box. See Section 1.4.9 and the installation instructions provided with the PIM for the maximum recommended cable lengths and detailed installation instructions.

2.6.1 PIM to Generator Set Connections

The PIM communicates with the RDC2 generator set controller. Connect the PIM module to the generator set as shown in Section 1.4.9.




Figure 2-6 Programmable Interface Module (PIM) (covered removed for illustration)

2.6.2 PIM Inputs and Outputs

Connect customer-supplied equipment to the PIM as instructed in TT-1584.

Factory-default settings for the outputs are shown in Figure 2-7. The outputs are controlled by the RDC2 controller. The run output is activated when the generator set is running. The common fault output is activated on a fault.

Use a personal computer running Kohler® OnCue® Plus or SiteTech™ software to assign functions to the other inputs and outputs, and/or change the settings for factory-set inputs and outputs. Verify that the input and output assignments match the connections to the PIM terminal strip.

Outputs 3 through 6 can also be controlled remotely using the OnCue® Plus program. If an output is activated or deactivated through OnCue Plus, it is no longer controlled by the RDC2 controller. See the OnCue Plus Software Operation Manual for instructions.


PIM Connection	Factory Default Setting
Input 1	None
Input 2	None
Output 1 (Relay 1)	Run
Output 2 (Relay 2)	Common Fault
Output 3 (Relay 3)	Low Battery Voltage (programmable)
Output 4 (Relay 4)	Not in Auto (programmable)
Output 5 (Relay 5)	Cooldown (programmable)
Output 6 (Relay 6)	Normal Source Failure
	(programmable)

Figure 2-7 PIM Factory Settings


42 Section 2 Accessories TP-7202 6/22

2.7 Engine Heaters

Block heaters and oil pan heaters are available in 120 V and 240 V versions. One block heater or oil pan heater is recommended for applications where the generator set is frequently subjected to temperatures below 0° C (32°F). In applications where the temperature falls below -18°C (0°F), installation of both heaters is recommended.



Accessing the middle compartment on the control panel. Hazardous voltage will cause severe injury or death. On the controller base box and automatic voltage regulator, do not touch the terminals for voltage and current measurement. Disconnect all power sources and disable the generator set before servicing.



Servicing the engine heater. Hot parts can cause minor personal injury or property damage. Install the heater before connecting it to power. Operating the heater before installation can cause burns and component damage. Disconnect power to the heater and allow it to cool before servicing the heater or nearby parts.

Servicing the engine oil pan heater. Heated components can cause severe injury. The oil pan heater will rapidly become hot when energized. Do not touch the oil pan heater while it is hot. Disconnect power to the engine oil pan heater and allow to cool before servicing it or nearby parts.


2.7.1 Oil Pan Heaters


The oil pan heater adheres to the bottom of the oil pan and heats the oil pan when the ambient temperature falls below 2°C (40°F), making starting easier and warmup guicker.

To energize the oil pan heater when the generator set is not running, the oil pan heater must be connected to a utility power source.

See TT-1633, provided with the oil pan heater kit, for detailed installation and connection instructions.

2.7.2 Block Heaters





Note: Block heater damage. The block heater will fail if the energized heater element is not immersed in coolant. Fill the cooling system before turning on the block heater. Run the engine until it is warm and refill the radiator to purge the air from the system before energizing the block heater.

The generator set engine is equipped with valves that eliminate the need to drain the cooling system before installing the block heater. Refer to the installation instructions provided with the block heater kit.

Connect the block heater to a power source that is energized when the generator set is not running.

TP-7202 6/22 Section 2 Accessories 43




Figure 2-8 Oil Pan Heater




Figure 2-9 Block Heater

44 Section 2 Accessories TP-7202 6/22

Section 3 Generator Reconnection

3.1 Voltage Reconnection

The reconnection procedure explains voltage reconnections only. Do not attempt to change the frequency (e.g. from 60 Hz to 50 Hz) in the field.

The following instructions explain the reconnection of 12-lead generator sets. In all cases, follow the National Electrical Code (NEC) guidelines.

Reconnect the stator leads of the generator set if a different output phase or voltage is desired. Refer to the following procedure and the connection schematics. Follow all safety precautions at the front of this manual and in the text while performing this procedure.

Note: Order voltage reconnection decal 246242 from an authorized service dealer and affix decal to generator set after reconnecting to a voltage different than the nameplate.



Accidental starting.
Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.



Hazardous voltage. Moving parts. Will cause severe injury or death.


Operate the generator set only when all guards and electrical enclosures are in place.

Grounding electrical equipment. Hazardous voltage will cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Short circuits. Hazardous voltage/current will cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

3.2 Four-Lead (Single-Phase) Generator Sets

Figure 3-1 shows the factory connection for the single-phase 120/240 V 60 Hz generator set. Four-lead, single-phase models are not reconnectable.



Note: Some stators have dual leads. Always connect leads of the same label together.

Some 4E, 4-lead dedicated single-phase stators have dual leads labeled 1, 2, 3, 4, and 1A, 2A, 3A, and 4A. In this case, connect 1 to 1A, 2 to 2A, 3 to 3A, and 4 to 4A.

Figure 3-1 Single-Phase Factory Connection, 120/240 V 60 Hz

3.3 12-Lead (Three-Phase) Generator Sets

Three-phase, 12-lead generator sets are reconnectable to the voltages and phases shown on the generator set specification sheet. See Figure 3-2 and Figure 3-3 for the applicable three-phase configurations and single-phase dogleg configuration. Use the following procedure to reconnect the generator to the desired voltage configuration, change the system voltage setting, and adjust the output voltage.

Note: Equipment damage. Verify that the voltage ratings of the transfer switch, line circuit breakers, and other accessories match the selected line voltage.

Reconnection Procedure

- 1. Press the OFF button on the RDC2 controller.
- Disconnect engine starting battery, negative (-) lead first.
- 3. Disconnect utility power to the generator set.
- Select desired voltage connection. See Figure 3-3.
 Connect the leads according to the diagram for desired phase and voltage.
- 5. Reconnect generator set engine starting battery, negative (-) lead last.
- Follow the instructions in Section 3.4 to enter the RDC2 Genset System menu. Check the system voltage, frequency, and phase settings, and change them if necessary.
- Connect a digital multimeter (DVM) to the generator set output.
- 8. Press RUN to start the generator set.
- Use a voltmeter to check for the correct voltage output from the generator set. Follow the instructions in Section 3.5 to calibrate the voltage on the RDC2 controller, if necessary.
- 10. Press OFF to stop the generator set.
- 11. Reconnect utility power to the generator set.
- 12. Press AUTO to place the generator set in automatic mode.




Figure 3-2 12-Lead Generator Reconnection, 1 of 2




Figure 3-3 12-Lead Generator Reconnection, 2 of 2

3.4 Changing System Settings

The RDC2 controller's keypad and display allow the installer to check and change the generator system settings, if necessary. The system settings for each generator model are set at the factory and should not normally require changes. Check the genset system settings and change them, if necessary, after generator reconnection or controller replacement.

The following procedure explains how to change the system settings. The procedure is also illustrated in Figure 3-6.

Procedure to Change System Settings

- Press the Select button to enter the main menu. See Figure 3-4 and Figure 3-5. The Overview screen will be displayed.
- 2. Press the down arrow button to navigate to the Genset System menu. See Figure 3-5.
- 3. Press the Select button to enter the Genset System menu. See Figure 3-6.
- 4. Press the down arrow button to step through the generator set system settings to the setting that you wish to change.
- 5. When the setting is displayed (for example, System Voltage), press the select button. The value will flash.
- 6. Press the up or down arrow buttons to increase or decrease the setting.

- When the desired setting is shown, press Select. The value stops flashing and the new setting is saved.
- 8. Press the down arrow to step to the next setting.
- To exit, press the down arrow button until Return is displayed. Press the Select button to exit the menu.
- Press the AUTO or OFF button to exit the main menu.

Note: If no buttons are pushed, the controller exits the menus and returns to the generator set status display after 5 minutes.




Figure 3-4 RDC2 Controller User Interface




Figure 3-5 RDC2 Main Menu

Changing System Settings on the RDC2 Controller							
Press the Select button to enter the main menu.			7. When the desired setting is shown, press Select. The value stops flashing.				
Press:	\odot	Display:	Overview> 1.2 h	Press:	\odot	Display:	System Voltage 220 V
		n arrow butto menu. See	on to navigate to the Figure 3-5.	8. Pres	s the down	arrow to ste	o to the next setting.
Press:	\searrow	Display:	Genset> System	Press:	\bigvee	Display:	System Freq: 60 Hz
Press the Select button to enter the genset system menu.				9. To exit, press the down arrow button until Return is displayed.			
Press:	\odot	Display:	System Voltage: 240 V	Press:	\searrow	Display:	Return>
Press the down arrow button, if necessary, to step to the setting that you want to change.			10. Press the Select button to exit the menu.				
 When the setting is displayed (for example, System Voltage), press the select button. The value will flash. 			Press:	\odot	Display:	Overview> 1.2 h	
Press:	\odot	Display:	System Voltage 240 V	ment	us and ret	-	ontroller to exit the generator set status
Press the up or down arrow buttons to increase or decrease the setting.			display		Display:	Genset State Standby	
Press:	\searrow	Display:	System Voltage 220 V		AUTO	Į.	
						are pushed, display afte	the controller returns r 5 minutes.

Figure 3-6 Changing Genset System Settings

3.5 Voltage Calibration



Hazardous voltage. Moving parts. Will cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.

Testing live electrical circuits. Hazardous voltage or current will cause severe injury or death. Have trained and qualified personnel take diagnostic measurements of live circuits. Use adequately rated test equipment with electrically insulated probes and follow the instructions of the test equipment manufacturer when performing voltage tests. Observe the following precautions when performing voltage tests: (1) Remove all jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Do not touch the enclosure or components inside the enclosure. (4) Be prepared for the system to operate automatically. (600 volts and under)

Short circuits. Hazardous voltage/current will cause **severe injury or death.** Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Correct voltage calibration is necessary for proper generator set operation. Check the voltage calibration after controller replacement or generator set reconnection, and adjust if necessary.

The RDC2 controller can be calibrated using the controller keypad and menus, or using a personal computer with Kohler® SiteTech™ software.

3.5.1 Calibration using the RDC2 **Controller Keypad and Menus**

The controller's voltage calibration can be adjusted using the controller keypad. See Figure 3-7 and follow the procedure below.

Note: A digital voltmeter is required for these adjustments.

- 1. With the generator set off, connect a digital multimeter to measure output voltage across L1 and L2. Set the meter to measure AC volts.
- 2. Start the generator set by pressing the RUN button on the RDC2 controller.
- 3. On the RDC2 controller, press the Select button and then use the arrow buttons to navigate to the Generator Metering menu on the RDC2 controller.
- 4. Press the Select button to display Volts L1-L2. Compare the number displayed with the voltmeter reading.
- 5. If the correct voltage is not displayed, follow these steps to adjust it:
 - a. Press the Select button. The voltage will flash.
 - b. Press the up or down arrow button to adjust the voltage to match the voltmeter reading.
 - c. Press Select to save the voltage setting. The voltage stops flashing.
 - d. Wait for the voltmeter reading to stabilize. This may take 30 to 60 seconds.
- 6. For three-phase models, press the Down arrow button and repeat the calibration procedure for voltage across L2-L3 and L3-L1.
- 7. Use the arrow buttons to step down to the Return screen. Press Select to exit the Generator Metering menu.
- 8. Press OFF to stop the generator set.

Reset Calibration

Pressing the select button when "Reset Calibration? Yes" is displayed will discard the changes and reset the calibration to the original settings. See Figure 3-7.




Figure 3-7 Voltage Calibration

3.5.2 Calibration Using SiteTech

Voltage calibration factors can be adjusted using SiteTech software to calibrate the RDC2 controller. Connect a personal computer (laptop) to the controller using a USB cable and follow this procedure to use Kohler® SiteTech™ software to calibrate the controller.

The voltage calibration factors are located in the Genset Calibration group in SiteTech™. Find the parameter labelled Genset Calibration Factor Voltage, L1-L2. See Figure 3-9.

Note: A digital voltmeter is required for these adjustments.

- 1. With the generator set off, connect a digital multimeter to measure output voltage across L1 and L2. Set the meter to measure AC volts.
- 2. Start the generator set by pressing the RUN button on the RDC2 controller.
- 3. Compare the voltage reading on the digital voltmeter to the voltage displayed by the controller.
- 4. If the voltage displayed on the controller does not match the measured voltage, use the equation in Figure 3-8 to calculate a new value for Genset Calibration Factor Voltage, L1-L2.
- Type the new value for Genset Calibration Factor Voltage, L1-L2 into SiteTech and click on Apply Changes. See Figure 3-9.
- Allow a few seconds for the controller to adjust to the new factor and then compare the voltmeter reading with the voltage displayed on the controller.
- If the voltage readings do not match, check your calculations. Check the calibration factor and both voltage readings again. Repeat the procedure using the new values, if necessary.

Note: If you would like to simplify the calculation, set the calibration factor to 1.0000 and then repeat the calibration procedure from step 3.

- 8. Repeat the procedure for voltage across L2-L3 and L3-L1, if necessary. (Three-phase only.)
- 9. Press OFF to stop the generator set.

$$(V_{meter} \div V_{control}) \times F_{old} = F_{new}$$

V_{meter} = Voltmeter reading

V_{control} = Voltage displayed on controller

F_{old} = Genset Calibration Factor Voltage, L1-L2, from SiteTech before calibration

F_{new} = New value to enter for Genset Calibration Factor Voltage, L1-L2, in SiteTech

Example:

Voltmeter reading: 241.2

Controller display: 240

Old calibration factor (from SiteTech): 1.0063

New calibration factor:

 $(241.2 \div 240) \times 1.0063 = 1.0113$

Figure 3-8 Voltage Calibration Factor




Figure 3-9 Voltage Calibration Factor in SiteTech™

Notes

Section 4 Diagrams and Drawings

This section contains dimension drawings, wiring diagrams, and schematics for the enclosed generator set. Figure 4-1 lists the drawing numbers and page numbers. Drawings are arranged in alphanumeric order on the following pages. See the generator set Operation Manual for service views, if necessary.

	24RCLA	24RCLA		30RCLA, 38RCLC	
Drawing Description	Drawing Number	Page	Drawing Number	Page	
Dimension Drawing:					
Dimensions	ADV-9758, 1 of 2	59	ADV-9759, 1 of 2	61	
Installation clearances	ADV-9758, 2 of 2	60	ADV-9759, 2 of 2	62	
Wiring Diagrams:					
Generator sets built before May, 2022:					
Schematic:					
Generator Set, Sheet 1	ADV-9765, 1 of 2	65	ADV-9761, 1 of 2	63	
Generator Set, Sheet 2	ADV-9765, 2 of 2	66	ADV-9761, 2 of 2	64	
Wiring Diagram:					
Generator Set, Sheet 1	GM116395, 1 of 2	72	GM116356, 1 of 2	70	
Generator Set, Sheet 2	GM116395, 2 of 2	73	GM116356, 2 of 2	71	
Generator sets built after May, 2022 with engine part number GM117219:					
Schematic:					
Generator Set, Sheet 1	ADV-9793, 1 of 3	67	No Change		
Generator Set, Sheet 2	ADV-9793, 2 of 3	68			
Generator Set, Sheet 3	ADV-9793, 3 of 3	69			
Wiring Diagram:					
Generator Set, Sheet 1	GM117394, 1 of 3	74	No Change		
Generator Set, Sheet 2	GM117394, 2 of 3	75			
Generator Set, Sheet 3	GM117394, 3 of 3	76			

Figure 4-1 Drawing Numbers and Locations

Notes

58 TP-7202 6/22




Figure 4-2 Dimension Drawing, 24RCLA Generator Set, ADV-9758, Sheet 1 of 2




Figure 4-3 Dimension Drawing, 24RCLA Generator Set, ADV-9758, Sheet 2 of 2

So Section 4 Diagrams and Drawings TP-7202 6/22




Figure 4-4 Dimension Drawing, 30RCLA/38RCLC, ADV-9759, Sheet 1 of 2




Figure 4-5 Dimension Drawing, 30RCLA/38RCLC, ADV-9759, Sheet 2 of 2

S2 Section 4 Diagrams and Drawings TP-7202 6/22




Figure 4-6 Schematic Diagram, 30RCLA/38RCLC, ADV-9761, Sheet 1 of 2




Figure 4-7 Schematic Diagram, 30RCLA/38RCLC, ADV-9761, Sheet 2 of 2




Figure 4-8 Schematic Diagram, 24RCLA Generator Set, ADV-9765, Sheet 1 of 2




Figure 4-9 Schematic Diagram, 24RCLA Generator Set, ADV-9765, Sheet 2 of 2




Figure 4-10 Schematic Diagram, 24RCLA Generator Set, ADV-9793, Sheet 1 of 3




Figure 4-11 Schematic Diagram, 24RCLA Generator Set, ADV-9793, Sheet 2 of 3




Figure 4-12 Schematic Diagram, 24RCLA Generator Set, ADV-9793, Sheet 3 of 3




Figure 4-13 Wiring Diagram, 30RCLA/38RCLC Generator Set, GM116356, Sheet 1 of 2




Figure 4-14 Wiring Diagram, 30RCLA/38RCLC Generator Set, GM116356, Sheet 2 of 2

71




Figure 4-15 Wiring Diagram, 24RCLA Generator Set, GM116395, Sheet 1 of 2




Figure 4-16 Wiring Diagram, 24RCLA Generator Set, GM116395, Sheet 2 of 2

73




Figure 4-17 Wiring Diagram, 24RCLA Generator Set, GM117394, Sheet 1 of 3




Figure 4-18 Wiring Diagram, 24RCLA Generator Set, GM117394, Sheet 2 of 3

75




Figure 4-19 Wiring Diagram, 24RCLA Generator Set, GM117394, Sheet 3 of 3

Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

	9				
A, amp	ampere	CG	center of gravity	ext.	external
ABDC	after bottom dead center	CID	cubic inch displacement	F	Fahrenheit, female
AC	alternating current	CL	centerline	FHM	flat head machine (screw)
A/D	analog to digital	cm	centimeter	fl. oz.	fluid ounce
	0 0				
ADC	advanced digital control;	CMOS	complementary metal oxide	flex.	flexible
	analog to digital converter		substrate (semiconductor)	freq.	frequency
adj.	adjust, adjustment	com	communications (port)	FS	full scale
AĎV	advertising dimensional	coml	commercial	ft.	foot, feet
	drawing		Commercial/Recreational		
Ah	. •			ft. lb.	foot pounds (torque)
	amp-hour	conn.	connection	ft./min.	feet per minute
AHWT	anticipatory high water	cont.	continued	ftp	file transfer protocol
	temperature	CPVC	chlorinated polyvinyl chloride	g	gram
AISI	American Iron and Steel	crit.	critical	-	
	Institute	CSA	Canadian Standards	ga.	gauge (meters, wire size)
ALOP	anticipatory low oil pressure	USA		gal.	gallon
alt.	alternator	~-	Association	gen.	generator
		CT	current transformer	genset	generator set
Al	aluminum	Cu	copper	ĞFI	ground fault interrupter
ANSI	American National Standards	cUL	Canadian Underwriter's	_	•
	Institute (formerly American		Laboratories	GND, ⊕	ground
	Standards Association, ASA)	CUL	Canadian Underwriter's	gov.	governor
AO	anticipatory only	COL		gph	gallons per hour
APDC	Air Pollution Control District		Laboratories		gallons per minute
		cu. in.	cubic inch	gpm	• .
API	American Petroleum Institute	CW.	clockwise	gr.	grade, gross
approx.	approximate, approximately	CWC	city water-cooled	GRD	equipment ground
APU	Auxiliary Power Unit	cyl.	cylinder	gr. wt.	gross weight
AQMD	Air Quality Management District			•	height by width by depth
	, ,	D/A	digital to analog		
AR	as required, as requested	DAC	digital to analog converter	HC	hex cap
AS	as supplied, as stated, as	dB	decibel	HCHT	high cylinder head temperature
	suggested	dB(A)	decibel (A weighted)	HD	heavy duty
ASE	American Society of Engineers	DC DC	direct current	HET	high exhaust temp., high
ASME	American Society of				engine temp.
, tolling	Mechanical Engineers	DCR	direct current resistance	hex	
0001		deg., °	degree		hexagon
assy.	assembly	dept.	department	Hg	mercury (element)
ASTM	American Society for Testing	dia.	diameter	HH	hex head
	Materials			HHC	hex head cap
ATDC	after top dead center	DI/EO	dual inlet/end outlet	HP	horsepower
ATS	automatic transfer switch	DIN	Deutsches Institut fur Normung		hour
auto.	automatic		e. V. (also Deutsche Industrie	hr.	
			Normenausschuss)	HS	heat shrink
aux.	auxiliary	DIP	dual inline package	hsg.	housing
avg.	average	DPDT	double-pole, double-throw	HVAC	heating, ventilation, and air
AVR	automatic voltage regulator	DPST	double-pole, single-throw		conditioning
AWG	American Wire Gauge			HWT	high water temperature
AWM	appliance wiring material	DS	disconnect switch		
		DVR	digital voltage regulator	Hz	hertz (cycles per second)
bat.	battery	E ² PROM,	EEPROM	IBC	International Building Code
BBDC	before bottom dead center	•	electrically-erasable	IC	integrated circuit
BC	battery charger, battery		programmable read-only	ID	inside diameter, identification
	charging		memory	IEC	International Electrotechnical
BCA	battery charging alternator	E, emer.	emergency (power source)	ILO	Commission
BCI				ıccc	
	Battery Council International	ECM	electronic control module,	IEEE	Institute of Electrical and
BDC	before dead center		engine control module		Electronics Engineers
BHP	brake horsepower	EDI	electronic data interchange	IMS	improved motor starting
blk.	black (paint color), block	EFR	emergency frequency relay	in.	inch
	(enginë)	e.g.	for example (exempli gratia)	in. H₂O	inches of water
BMEP	brake mean effective pressure	EG.	electronic governor	-	
	bits per second			in. Hg	inches of mercury
bps	•	EGSA	Electrical Generating Systems	in. lb.	inch pounds
br.	brass		Association	Inc.	incorporated
BTDC	before top dead center	EIA	Electronic Industries	ind.	industrial
Btu	British thermal unit		Association	int.	internal
Btu/min.	British thermal units per minute	EI/EO	end inlet/end outlet	int./ext.	
,	•	EMI	electromagnetic interference	,	internal/external
C .	Celsius, centigrade		•	I/O	input/output
cal.	calorie	emiss.	emission	IΡ	internet protocol
CAN	controller area network	eng.	engine	ISO	International Organization for
CARB	California Air Resources Board	EPA	Environmental Protection		Standardization
CAT5	Category 5 (network cable)		Agency	J	joule
		EPS	emergency power system		
CB	circuit breaker			JIS	Japanese Industry Standard
CC	crank cycle	ER	emergency relay	k	kilo (1000)
CC	cubic centimeter	ES	engineering special,	K	kelvin
CCA	cold cranking amps		engineered special	kA	kiloampere
		ESD	electrostatic discharge	KB	kilobyte (2 ¹⁰ bytes)
	· .	LOD		17.17	MINDUNE IZ DVIESI
ccw.	counterclockwise		estimated		
ccw. CEC	counterclockwise Canadian Electrical Code	est.	estimated emergency stop	KBus	Kohler communication protocol
ccw.	counterclockwise	est. E-Stop	emergency stop		
ccw. CEC	counterclockwise Canadian Electrical Code	est. E-Stop etc.	emergency stop et cetera (and so forth)	KBus	Kohler communication protocol
ccw. CEC cert.	counterclockwise Canadian Electrical Code certificate, certification, certified	est. E-Stop	emergency stop	KBus	Kohler communication protocol

TP-7202 6/22 Appendix 77

kg/cm ²	kilograms per square	NC	normally closed	RTU	remote terminal unit
kg/ciii-	centimeter	NEC	National Electrical Code	RTV	room temperature vulcanization
kgm	kilogram-meter	NEMA	National Electrical	RW	read/write
kg/m ³	kilograms per cubic meter	INCINI	Manufacturers Association	SAE	Society of Automotive
kHz	kilohertz	NFPA	National Fire Protection	SAL	Engineers
kJ	kilojoule	INITA	Association	scfm	standard cubic feet per minute
km	kilometer	Nm	newton meter	SCR	silicon controlled rectifier
		NO	normally open		second
kOhm, kΩ kPa		no., nos.	number, numbers	s, sec. SI	
	kilopascal	NPS	National Pipe, Straight	SI	Systeme international d'unites, International System of Units
kph	kilometers per hour	NPSC		SI/EO	
kV	kilovolt		National Pipe, Straight-coupling		side in/end out
kVA	kilovolt ampere	NPT	National Standard taper pipe thread per general use	sil.	silencer
kVAR	kilovolt ampere reactive	NPTF	National Pipe, Taper-Fine	SMTP	simple mail transfer protocol
kW	kilowatt	NR	not required, normal relay	SN	serial number
kWh	kilowatt-hour			SNMP	simple network management protocol
kWm	kilowatt mechanical	ns OC	nanosecond	CDDT	•
kWth	kilowatt-thermal		overcrank	SPDT	single-pole, double-throw
L	liter	OD	outside diameter	SPST	single-pole, single-throw
LAN	local area network	OEM	original equipment	spec	specification
LxWxH	length by width by height	OF	manufacturer	specs	specification(s)
lb.	pound, pounds	OF	overfrequency	sq.	square
lbm/ft ³	pounds mass per cubic feet	opt.	option, optional	sq. cm	square centimeter
LCB	line circuit breaker	OS	oversize, overspeed	sq. in.	square inch
LCD	liquid crystal display	OSHA	Occupational Safety and Health	SMS	short message service
LED	light emitting diode	0)/	Administration	SS	stainless steel
Lph	liters per hour	OV	overvoltage	std.	standard
Lpm	liters per minute	OZ.	ounce	stl.	steel
LOP	low oil pressure	p., pp.	page, pages	tach.	tachometer
LP	liquefied petroleum	PC	personal computer	TB	terminal block
LPG	liquefied petroleum gas	PCB	printed circuit board	TCP	transmission control protocol
LS	left side	pF	picofarad	TD	time delay
	sound power level, A weighted	PF	power factor	TDC	top dead center
L _{wa} LWL	low water level	ph., \varnothing	phase	TDEC	time delay engine cooldown
LWT		PHC	Phillips® head Crimptite®	TDEN	time delay emergency to
	low water temperature		(screw)		normal
m	meter, milli (1/1000)	PHH	Phillips® hex head (screw)	TDES	time delay engine start
М	mega (10 ⁶ when used with SI	PHM	pan head machine (screw)	TDNE	time delay normal to
m ³	units), male	PLC	programmable logic control		emergency
	cubic meter	PMG	permanent magnet generator	TDOE	time delay off to emergency
m ³ /hr.	cubic meters per hour	pot	potentiometer, potential	TDON	time delay off to normal
m³/min.	cubic meters per minute	ppm	parts per million	temp.	temperature
mA	milliampere	PROM	programmable read-only	term.	terminal
man.	manual		memory	THD	total harmonic distortion
max.	maximum	psi	pounds per square inch	TIF	telephone influence factor
MB	megabyte (2 ²⁰ bytes)	psig	pounds per square inch gauge	tol.	tolerance
MCCB	molded-case circuit breaker	pt.	pint	turbo.	
MCM	one thousand circular mils	PTC	positive temperature coefficient		turbocharger
meggar	megohmmeter	PTO	power takeoff	typ.	typical (same in multiple locations)
MHz	megahertz	PVC	polyvinyl chloride	UF	underfrequency
mi.	mile	qt.	quart, quarts	UHF	
mil	one one-thousandth of an inch		quantity	UIF	ultrahigh frequency
min.	minimum, minute	qty. R	replacement (emergency)		user interface
misc.	miscellaneous	п	power source	UL	Underwriter's Laboratories, Inc.
MJ	megajoule	rad.	radiator, radius	UNC	unified coarse thread (was NC)
mJ	millijoule	RAM	random access memory	UNF	unified fine thread (was NF)
mm	millimeter		RS-485 proprietary	univ.	universal
mOhm, mg		RBUS	communications	URL	uniform resource locator
	Ωmegohm	RDO	relay driver output		(web address)
MOV	metal oxide varistor	ref.	reference	US	undersize, underspeed
MPa	megapascal			UV	ultraviolet, undervoltage
mpg	miles per gallon	rem.	remote	V	volt
mph	miles per gallon miles per hour		Residential/Commercial	VAC	volts alternating current
MS	military standard	RFI	radio frequency interference	VAR	voltampere reactive
ms	millisecond	RH	round head	VDC	volts direct current
		RHM	round head machine (screw)	VFD	vacuum fluorescent display
m/sec.	meters per second	rly.	relay	VGA	video graphics adapter
mtg.	mounting	rms	root mean square	VHF	very high frequency
MTU	Motoren-und Turbinen-Union	rnd.	round	W	watt
MW	megawatt	RO	read only	WCR	withstand and closing rating
mW	milliwatt	ROM	read only memory	w/	with
μF	microfarad	rot.	rotate, rotating	ŴΟ	write only
N, norm.	normal (power source)	rpm	revolutions per minute	w/o	without
NA	not available, not applicable	ŔS	right side	wt.	weight
nat. gas	natural gas	RTDs	Resistance Temperature	xfmr	transformer
NBS	National Bureau of Standards		Detectors		

78 Appendix TP-7202 6/22

Notes

TP-7202 6/22 79

